



# NGRM500

Neutral Grounding Resistor Monitor





**Bender GmbH & Co. KG**

Londorfer Str. 65 • 35305 Grünberg • Germany

P.O. Box 1161 • 35301 Grünberg • Germany

Tel.: +49 6401 807-0 • Fax: +49 6401 807-259

E-Mail: [info@bender.de](mailto:info@bender.de) • [www.bender.de](http://www.bender.de)

© Bender GmbH & Co. KG

All rights reserved.

Reprinting only with permission of the publisher.

Subject to change!

Photos: Bender archive.

# Table of Contents

|   |           |
|---|-----------|
| <b>1. Important information .....</b>   | <b>7</b>  |
| 1.1 How to use this manual .....  | 7         |
| 1.2 Technical support: service and support .....                              | 8         |
| 1.2.1 First level support .....   | 8         |
| 1.2.2 Repair service .....  | 8         |
| 1.2.3 Field service .....   | 8         |
| 1.3 Training courses .....  | 9         |
| 1.4 Delivery conditions .....   | 9         |
| 1.5 Inspection, transport and storage .....                                   | 9         |
| 1.6 Warranty and liability .....  | 9         |
| 1.7 Disposal .....  | 10        |
| <b>2. Safety instructions .....</b>   | <b>11</b> |
| 2.1 General safety instructions .....   | 11        |
| 2.2 Work activities on electrical installations .....                         | 11        |
| 2.3 Intended use .....  | 11        |
| 2.4 Glossary .....  | 12        |
| <b>3. Function .....</b>  | <b>13</b> |
| 3.1 Device features .....   | 13        |
| 3.2 Functional description .....  | 14        |
| 3.3 Recommended minimum value RNGR (tripping level 50 %) .....                | 15        |
| 3.3.1 Recommended RNGR for system voltage $U_{sys} \leq 4300 \text{ V}$ ..... | 15        |
| 3.3.2 Recommended RNGR for system voltage $U_{sys} > 4300 \text{ V}$ .....    | 16        |

|  |           |
|--|-----------|
| <b>4. Installation .....</b>   | <b>17</b> |
| 4.1 Dimension diagram NGRM500 .....  | 17        |
| 4.2 Enclosure views .....  | 18        |
| 4.3 Screw mounting .....   | 19        |
| 4.4 DIN rail mounting .....  | 20        |
| <b>5. Connection .....</b>   | <b>21</b> |
| 5.1 Connection requirements .....  | 21        |
| 5.2 Connection descriptions of CD-series coupling device .....                     | 22        |
| 5.3 Recommended connecting cable to coupling device CD... ..                       | 22        |
| 5.4 Star connection .....  | 23        |
| 5.4.1 Connection .....   | 23        |
| 5.4.2 Connection with pulser .....   | 24        |
| 5.4.3 Artificial neutral (delta connection) .....                                  | 25        |
| 5.5 CT connections .....   | 26        |
| 5.6 Connection to relay outputs<br>(Ground-fault, NGR-fault and Trip relays) ..... | 27        |
| 5.7 Connection to the X1 interface .....   | 28        |
| 5.7.1 X1: Input I1...3 .....   | 28        |
| 5.7.2 X1: Output Q1...2 .....  | 29        |
| 5.7.3 X1: Analogue output .....  | 30        |
| <b>6. User interface .....</b>   | <b>31</b> |
| 6.1 Operating elements .....   | 31        |
| 6.2 Standard display .....   | 33        |
| 6.3 Fault indication (active) .....  | 34        |
| 6.4 Fault indication (inactive) .....  | 35        |
| 6.5 Acknowledging a fault message .....  | 35        |
| 6.6 History memory .....   | 36        |

|  |           |
|--|-----------|
| <b>7. Menu</b>                               | <b>37</b> |
| 7.1 Overview                                 | 37        |
| 7.2 Navigating through the menu              | 38        |
| 7.3 Changing settings                        | 38        |
| 7.4 Data measured values (menu 1)            | 39        |
| 7.5 Harmonics (menu 2)                       | 39        |
| 7.6 History (menu 3)                         | 40        |
| 7.7 Pulser (menu 4)                          | 40        |
| 7.8 Display (menu 5)                         | 41        |
| 7.9 HRG settings (menu 6)                    | 41        |
| 7.9.1 HRG system (menu 6.1)                  | 41        |
| 7.9.2 CT (menu 6.2)                          | 42        |
| 7.9.3 NGR (menu 6.3)                         | 42        |
| 7.9.4 Response values (menu 6.4)             | 42        |
| 7.9.5 System settings (menu 6.5)             | 45        |
| 7.9.6 Field calibration (menu 6.6)           | 47        |
| 7.10 Device settings (menu 7)                | 47        |
| 7.11 Commissioning (menu 8)                  | 52        |
| 7.12 Info (menu 9)                           | 52        |
| 7.13 Alarm (menu 10)                         | 52        |
| <b>8. Initial commissioning</b>              | <b>53</b> |
| 8.1 Response values                          | 53        |
| 8.2 Output relays operating modes            | 54        |
| 8.2.1 Field calibration                      | 54        |
| 8.2.2 Trip times                             | 54        |
| 8.3 Trip signal: RMS, fundamental, harmonics | 57        |
| 8.4 Initial measurement                      | 57        |

|  |           |
|--|-----------|
| <b>9. Analogue and digital I/O configuration .....</b> | <b>59</b> |
| 9.1 Analogue output (menu 6.6.4) .....                 | 59        |
| 9.2 Digital outputs (Q1, Q2) .....                     | 59        |
| 9.2.1 Use of Q1: System condition .....                | 60        |
| 9.2.2 Use of Q2: Pulser .....                          | 60        |
| 9.3 Digital inputs .....                               | 60        |
| <b>10. Test cycle .....</b>                            | <b>61</b> |
| <b>11. Factory settings .....</b>                      | <b>63</b> |
| <b>12. Error codes .....</b>                           | <b>65</b> |
| <b>13. Technical data .....</b>                        | <b>67</b> |
| 13.1 Tabular data .....                                | 67        |
| 13.2 Ordering details .....                            | 72        |
| 13.2.1 NGR monitor .....                               | 72        |
| 13.2.2 Accessories .....                               | 72        |

# 1. Important information

## 1.1 How to use this manual



This manual is intended for **qualified personnel** working in electrical engineering and electronics!

**Always keep this manual within easy reach for future reference.** To make it easier for you to understand and revisit certain sections in this manual, we have used symbols to identify important instructions and information. The meaning of these symbols is explained below:



This signal word indicates that there is a **high risk of danger** that will result in **death** or **serious injury** if not avoided.



This signal word indicates a **medium risk** of danger that can lead to **death** or **serious injury**, if not avoided.



This signal word indicates a **low-level risk** that can result in minor or **moderate injury** or **damage to property** if not avoided.



This symbol denotes information intended to assist the user in making **optimum use** of the product.

## 1.2 Technical support: service and support

For commissioning and troubleshooting Bender offers:

### 1.2.1 First level support

Technical support by phone or e-mail for all Bender products

- Questions about specific customer applications
- Commissioning
- Troubleshooting

**Telephone:** +49 6401 807-760\*  
**Fax:** +49 6401 807-259  
In Germany only: 0700BenderHelp (Tel. and Fax)  
**E-mail:** support@bender-service.de

### 1.2.2 Repair service

Repair, calibration, update and replacement service for Bender products

- Repair, calibration, testing and analysis of Bender products
- Hardware and software update for Bender devices
- Delivery of replacement devices for faulty or incorrectly delivered Bender devices
- Extended warranty for Bender devices with in-house repair service or replacement devices at no extra cost

**Telephone:** +49 6401 807-780\*\* (technical issues)  
+49 6401 807-784\*\*, -785\*\* (commercial issues)  
**Fax:** +49 6401 807-789  
**E-mail:** repair@bender-service.de

Please send the devices for **repair** to the following address:

Bender GmbH, Repair-Service,  
Londorfer Straße 65,  
35305 Grünberg

### 1.2.3 Field service

On-site service for all Bender products

- Commissioning, parameter setting, maintenance, troubleshooting for Bender products
- Analysis of the electrical installation in the building (power quality test, EMC test, thermography)
- Practical training courses for customers

**Telephone:** +49 6401 807-752\*\*, -762 \*\* (technical issues)  
+49 6401 807-753\*\* (commercial issues)  
**Fax:** +49 6401 807-759  
**E-mail:** fieldservice@bender-service.de  
**Internet:** www.bender-de.com

\*Available from 7.00 a.m. to 8.00 p.m. on 365 days of the year (CET/UTC+1)

\*\*Mo-Thu 7.00 a.m. - 8.00 p.m., Fr 7.00 a.m. - 13.00 p.m

### 1.3 Training courses

Bender is happy to provide training regarding the use of test equipment. The dates of training courses and workshops can be found on the Internet at [www.bender-de.com](http://www.bender-de.com) -> Know-how -> Seminars.

### 1.4 Delivery conditions

The conditions of sale and delivery set out by Bender apply.

For software products, the "Softwareklausel zur Überlassung von Standard- Software als Teil von Lieferungen, Ergänzung und Änderung der Allgemeinen Lieferbedingungen für Erzeugnisse und Leistungen der Elektroindustrie" (software clause in respect of the licensing of standard software as part of deliveries, modifications and changes to general delivery conditions for products and services in the electrical industry) set out by the ZVEI (Zentralverband Elektrotechnik- und Elektronikindustrie e.V., (German Electrical and Electronic Manufacturers' Association) also applies.

Conditions of sale and delivery can be obtained from Bender in printed or electronic format.

### 1.5 Inspection, transport and storage

Inspect the dispatch and equipment packaging for damage, and compare the contents of the package with the delivery documents. In the event of damage in transit, please contact Bender immediately.

The devices must only be stored in areas where it is protected from dust, humidity and spray or dripping water, and in which the specified storage temperatures can be assured.

### 1.6 Warranty and liability

Warranty and liability claims in the event of injury to persons or damage to property are excluded if they can be attributed to one or more of the following causes:

- Improper use of the device.
- Incorrect mounting, commissioning, operation and maintenance of the device.

- Failure to observe the instructions in this operating manual regarding transport, commissioning, operation and maintenance of the device.
- Unauthorised changes to the device made by parties other than the manufacturer.
- Non-observance of technical data.
- Repairs carried out incorrectly and the use of replacement parts or accessories not approved by the manufacturer.
- Catastrophes caused by external influences and force majeure.
- Mounting and installation with device combinations not recommended by the manufacturer.

This operating manual, especially the safety instructions, must be observed by all personnel working on the device. Furthermore, the rules and regulations that apply for accident prevention at the place of use must be observed.

## 1.7 Disposal

Abide by the national regulations and laws governing the disposal of this device. Ask your supplier if you are not sure how to dispose of the old equipment.

The directive on waste electrical and electronic equipment (WEEE directive) and the directive on the restriction of certain hazardous substances in electrical and electronic equipment (RoHS directive) apply in the European Community. In Germany, these policies are implemented through the "Electrical and Electronic Equipment Act" (ElektroG).

According to this, the following applies:

- Electric and electronic equipment are not to be included in household waste.
- Batteries and accumulators are not to be included in household waste but must be disposed of in accordance with the regulations.
- Old electrical and electronic equipment from users other than private households which was introduced to the market after 13th August 2005 must be taken back by the manufacturer and disposed of properly.

For more information on the disposal of Bender devices, refer to our homepage at [www.bender.de](http://www.bender.de) -> Service & support.

## 2. Safety instructions

### 2.1 General safety instructions

Part of the device documentation in addition to this manual is the enclosed "Safety instructions for Bender products".

### 2.2 Work activities on electrical installations



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



**DANGER**

#### **Risk of electrocution due to electric shock!**

Touching live parts of the system carries the risk of:

- An electric shock
- Damage to the electrical installation
- Destruction of the device

**Before installing and connecting the device, make sure that the installation has been *de-energised*.** Observe the rules for working on electrical installations.

If the device is used outside the Federal Republic of Germany, the applicable local standards and regulations must be complied with. The European standard EN 50110 can be used as a guide.

### 2.3 Intended use

The NGRM500 is only intended for use in high-resistance grounded systems. In these systems, the NGRM500 monitors

- the current through the neutral grounding resistor (NGR),
- the voltage between the star point of the transformer and earth (voltage drop across the NGR),
- the condition of the neutral grounding resistor (NGR).



Systems with a high-resistance grounded star point can be used when an **interruption of the power supply would involve excessive costs due to production stoppage** (e.g. automotive production, chemical industry). The ground fault that occurs between a phase and earth does not require power-supply tripping in many of these systems. A ground fault must be detected and eliminated as quickly as practicable, since the occurrence of another ground fault in a second phase would cause an overcurrent protective device to trip.

In order to meet the requirements of applicable standards, customised parameter settings must be made on the device to configure it for local equipment and operating conditions. Any other use than that described in this manual is regarded as improper. Intended use includes following all the instructions in this manual.

## 2.4 Glossary

|                      |   |
|----------------------|---|
| <b>CD</b>            | <b>Coupling Device</b> CD-series                              |
| <b>CT</b>            | <b>C</b> urrent <b>T</b> ransformer                           |
| <b>FFT</b>           | <b>F</b> ast <b>F</b> ourier <b>T</b> ransformation           |
| <b>HRG</b>           | <b>H</b> igh <b>R</b> esistance <b>G</b> rounding             |
| $I_{\text{NGR}}$     | NGR rated current   |
| $I_{\text{NGR nom}}$ | Nominal current through the NGR                               |
| <b>NER</b>           | <b>N</b> eutral <b>E</b> arthing <b>R</b> esistor (NER = NGR) |
| <b>NGR</b>           | <b>N</b> eutral <b>G</b> rounding <b>R</b> esistor            |
| <b>NTP</b>           | <b>N</b> etwork <b>T</b> ime <b>P</b> rotocol                 |
| <b>PT</b>            | <b>P</b> otential <b>T</b> ransformer                         |
| $R_{\text{NGR}}$     | NGR resistance value  |
| $R_{\text{NGR nom}}$ | NGR nominal resistance  |
| $R_{\zeta}$          | Sense resistor; CD-series coupling device                     |
| <b>PLC</b>           | <b>P</b> rogrammable <b>L</b> ogic <b>C</b> ontroller         |
| $U_{\text{NGR}}$     | Voltage on the NGR  |
| $U_{\text{NGR nom}}$ | Nominal voltage across the NGR                                |
| $U_{\text{sys}}$     | System voltage  |
| <b>UTC</b>           | <b>U</b> niversal <b>T</b> ime <b>C</b> oordinated            |

---

## 3. Function

### 3.1 Device features

- Determination of  $R_{\text{NGR}}$  with passive and active measurement methods
- Continuous monitoring of the  $R_{\text{NGR}}$  even if the installation is de-energised;
- Alarm or trip on ground fault
- Monitoring of the current  $I_{\text{NGR}}$
- Monitoring of the voltage  $U_{\text{NGR}}$
- Ethernet communication
- Web server
- Language selection (German, English GB and US, Spanish, French)
- Test button (internal, external) with/without tripping
- FFT analysis of the measuring signals
- Pulser for manual ground fault location
- Relays to indicate ground faults and resistor faults
- Relay for shutdown of the power system after a configurable time
- Can be combined with RCMS... for automatic shutdown of feeders
- Graphical user interface
- Wide supply voltage range
- Range of use up to 2000 m AMSL
- Fault/History memory
- Analogue output of measured values (0...10 V, 4...20 mA, selectable parameters)
- Password protection
- Tripping on RMS, fundamental or configurable filter
- Detection of AC and DC ground faults

### 3.2 Functional description

The NGRM500 monitors NGR resistance  $R_{\text{NGR}}$ , neutral voltage  $U_{\text{NGR}}$  and current  $I_{\text{NGR}}$ . NGR resistance is measured using an active and a passive procedure:

- |         |   |
|---------|---|
| active  | The device generates an active test pulse and measures $R_{\text{NGR}}$ even if the installation is de-energised.   |
| passive | The resistance $R_{\text{NGR}}$ is determined when $I_{\text{NGR}}$ or $U_{\text{NGR}}$ exceeds an internal threshold. The device measures the existing current and voltage and calculates $R_{\text{NGR}}$ . |

When the "auto" setting is selected, monitoring switches automatically between "active" and "passive" when neutral current or voltage exceeds or falls below the internal threshold. The threshold is 15 % of the nominal value and can be adjusted by Bender service if required.

A short circuit or interruption of the NGR is reliably detected in an energised as well as a de-energised installation with the active measurement method.

When the "passive" setting is selected, no switching between passive and active methods takes place. NGR resistance will not be monitored while the power system is de-energised, or when current and voltage are low.

The NGR fault relay output switches from alarm state to operating state when the measured resistance  $R_{\text{NGR}}$  is within the configured thresholds.

A ground fault is signalled via the corresponding Ground-fault relay and front panel GROUND FAULT LED, when  $I_{\text{NGR}}$  or  $U_{\text{NGR}}$  exceeds the setting. After the adjustable time delay has elapsed, the power system can be shut down by means of the Trip relay. When the ground-fault has been removed, the alarm will auto-reset, or can be reset if so configured.

Power systems from 400 V...25 kV can be monitored via the appropriate CD-series coupling device.

$I_{\text{NGR}}$  is measured with **measuring current transformers** with a 5 A or 50 mA secondary.

### 3.3 Recommended minimum value $R_{NGR}$ (tripping level 50 %)

Temperature range  $-40\dots+70\text{ }^{\circ}\text{C}$ , field calibration at  $25\text{ }^{\circ}\text{C}$

(Values shown in brackets: Limited temperature range  $0\dots+40\text{ }^{\circ}\text{C}$ , field calibration at  $25\text{ }^{\circ}\text{C}$ )

#### 3.3.1 Recommended $R_{NGR}$ for system voltage $U_{sys} \leq 4300\text{ V}$

| $U_{sys}$ | CD1000/CD1000-2 |                |                | CD1000-2       | CD5000         |                |
|-----------|-----------------|----------------|----------------|----------------|----------------|----------------|
|           | 400 V           | 600 V          | 690 V          | 1000 V         | 2400 V         | 4200 V         |
| $I_{NGR}$ |                 |                |                |                |                |                |
| 1 A       | 231 $\Omega$    | 346 $\Omega$   | 398 $\Omega$   | 577 $\Omega$   | 1386 $\Omega$  | —              |
| 5 A       | 46 $\Omega$     | 69 $\Omega$    | 80 $\Omega$    | 115 $\Omega$   | 277 $\Omega$   | 485 $\Omega$   |
| 10 A      | (23 $\Omega$ )  | 35 $\Omega$    | 40 $\Omega$    | 58 $\Omega$    | 139 $\Omega$   | 242 $\Omega$   |
| 15 A      | (15 $\Omega$ )  | (23 $\Omega$ ) | (27 $\Omega$ ) | 38 $\Omega$    | 92 $\Omega$    | 162 $\Omega$   |
| 20 A      | —               | (17 $\Omega$ ) | (20 $\Omega$ ) | 29 $\Omega$    | 69 $\Omega$    | 121 $\Omega$   |
| 25 A      | —               | —              | (16 $\Omega$ ) | (23 $\Omega$ ) | 55 $\Omega$    | 97 $\Omega$    |
| 30 A      | —               | —              | —              | (19 $\Omega$ ) | (46 $\Omega$ ) | 81 $\Omega$    |
| 40 A      | —               | —              | —              | —              | (35 $\Omega$ ) | 61 $\Omega$    |
| 50 A      | —               | —              | —              | —              | (28 $\Omega$ ) | (48 $\Omega$ ) |
| 100 A     | —               | —              | —              | —              | —              | (24 $\Omega$ ) |

Tab. 3.1: Recommended  $R_{NGR}$  for system voltage  $U_{sys} \leq 4300\text{ V}$

### 3.3.2 Recommended $R_{NGR}$ for system voltage $U_{sys} > 4300$ V

|           | CD14400         |                 |                 |                 |                 | CD25000         |
|-----------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| $U_{sys}$ | 6000 V          | 6600 V          | 7200 V          | 11000 V         | 14 400 V        | 25 000 V        |
| $I_{NGR}$ |                 |                 |                 |                 |                 |                 |
| 1 A       | —               | —               | —               | —               | —               | —               |
| 5 A       | 693 $\Omega$    | 762 $\Omega$    | 831 $\Omega$    | 1270 $\Omega$   | 1663 $\Omega$   | —               |
| 10 A      | 346 $\Omega$    | 381 $\Omega$    | 416 $\Omega$    | 635 $\Omega$    | 831 $\Omega$    | 1443 $\Omega$   |
| 15 A      | 231 $\Omega$    | 254 $\Omega$    | 277 $\Omega$    | 423 $\Omega$    | 554 $\Omega$    | 962 $\Omega$    |
| 20 A      | (173 $\Omega$ ) | 191 $\Omega$    | 208 $\Omega$    | 318 $\Omega$    | 416 $\Omega$    | 722 $\Omega$    |
| 25 A      | (139 $\Omega$ ) | (152 $\Omega$ ) | (166 $\Omega$ ) | 254 $\Omega$    | 333 $\Omega$    | 577 $\Omega$    |
| 30 A      | (115 $\Omega$ ) | (127 $\Omega$ ) | (139 $\Omega$ ) | 212 $\Omega$    | 277 $\Omega$    | 481 $\Omega$    |
| 40 A      | (87 $\Omega$ )  | (95 $\Omega$ )  | (104 $\Omega$ ) | (159 $\Omega$ ) | 208 $\Omega$    | 361 $\Omega$    |
| 50 A      | —               | (76 $\Omega$ )  | (83 $\Omega$ )  | (127 $\Omega$ ) | (166 $\Omega$ ) | 289 $\Omega$    |
| 100 A     | —               | —               | —               | —               | (83 $\Omega$ )  | (144 $\Omega$ ) |

Tab. 3.2: Recommended  $R_{NGR}$  for system voltage  $U_{sys} > 4300$  V

## 4. Installation



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



*Risk of electrocution due to electric shock!*

*Touching live parts of the system carries the risk of:*

- An electric shock
- Damage to the electrical installation
- Destruction of the device

**Before installing and connecting the device, make sure that the installation has been de-energised.** Observe the rules for working on electrical installations.

### 4.1 Dimension diagram NGRM500




Fig. 4.1: Dimension diagram NGRM500; All dimensions in mm (in)

## 4.2 Enclosure views





Fig. 4.2: Enclosure view: top, front, bottom

### 4.3 Screw mounting


1. Fix the three mounting clips delivered with the device (two of them packed separately) manually or using a tool, as illustrated below.
2. Drill the mounting holes for the M4 thread according to the drilling template.
3. Fix the NGRM500 using three M4 screws.



Dimensions in mm (in)

## 4.4 DIN rail mounting

1. Fix the three mounting clips delivered with the device (two of them packed separately) manually or using a tool, as illustrated below.
2. Snap the NGRM500 on the DIN rail.
3. Fix the NGRM500 to the DIN rail by pushing the mounting clips until they click into place.



*Dimensions in mm (in)*

## 5. Connection

### 5.1 Connection requirements



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



**DANGER**

#### **Risk of electrocution due to electric shock!**

Touching live parts of the system carries the risk of:

- An electric shock
- Damage to the electrical installation
- Destruction of the device

**Before installing and connecting the device, make sure that the installation has been de-energised.** Observe the rules for working on electrical installations.



**CAUTION**

#### **Provide line protection!**

According to DIN VDE 0100-430, a line protection shall be provided for the supply voltage.



#### **Check proper connection.**


Prior to commissioning of the installation, check that the device has been properly connected and check that the device functions.



#### **For UL applications:**

- Use 60/70 °C copper wires only.
- For UL and CSA applications, the supply voltage must be protected via **5 A** fuses.

## 5.2 Connection descriptions of CD-series coupling device



## 5.3 Recommended connecting cable to coupling device CD...

| CD...              | Connection CD...      | Cable lug | Metrical              | Imperial          |
|--------------------|-----------------------|-----------|-----------------------|-------------------|
| CD1000             | N, G1, G              | —         | 1.5 mm <sup>2</sup>   | AWG 16            |
| CD1000-2           | N, R <sub>S</sub> , E | —         | 1.5 mm <sup>2</sup>   | AWG 16            |
|                    | PE                    | M4        | ≥ 1.5 mm <sup>2</sup> | AWG 16 or greater |
| CD5000             | G1, G                 | —         | 1.5 mm <sup>2</sup>   | AWG 16            |
|                    | N                     | M8 or M10 | ≥ 1.5 mm <sup>2</sup> | AWG 16 or greater |
|                    | PE                    | M6        | ≥ 1.5 mm <sup>2</sup> | AWG 16 or greater |
| CD14400<br>CD25000 | R <sub>S</sub> , E    | —         | 1.5 mm <sup>2</sup>   | AWG 16            |
|                    | N                     | M5 or M10 | ≥ 1.5 mm <sup>2</sup> | AWG 16 or greater |
|                    | PE                    | M5        | ≥ 1.5 mm <sup>2</sup> | AWG 16 or greater |

## 5.4 Star connection

### 5.4.1 Connection





Fig. 5.1: Star configuration



The "N" connection of the CD-series coupling device should be as close to the transformer star point as possible.

**5.4.2 Connection with pulser**



*Fig. 5.2: Connection with pulser*



The "N" connection of the CD-series coupling device should be as close to the transformer star point as possible.



An intermediate relay may be required between the power contactor of the pulser and digital output X1.

### 5.4.3 Artificial neutral (delta connection)

If no star point is available, the following circuit can create an artificial neutral.

#### Connection with a zigzag transformer










Fig. 5.3: Artificial neutral with a zigzag transformer

## 5.5 CT connections

Depending on the system to be monitored, a suitable measuring current transformer has to be chosen. All common measuring current transformers (50 mA or 5 A on the secondary side) can be used. The following table helps you with the choice:

| System type                           | AC + DC  | AC  | AC   |
|---------------------------------------|--|---|--|
| $I_{NGR}$                             | 1...25 A   | 5...25 A  | 5...100 A  |
| Frequency response range              | 0...3800 Hz  | 42...3800 Hz  | 50/60 Hz   |
| Bender CT Ratio                       | 600:1  | 600:1   | 60:5   |
| Connecting cable                      | W...AB: max. 10 m<br>CTUB103: max. 30 m  | max. 40 m   | max. 25 m<br>(4 mm <sup>2</sup> /AWG 12)   |
|                                       | provided cable or cable of 0.75...1.5 mm <sup>2</sup> /AWG 18...16)  |   | max. 40 m<br>(6 mm <sup>2</sup> /AWG 10)   |
| $I_{\Delta n}$<br>(Currents detected) | <br>AC, pulsed AC, DC   | <br>AC, pulsed AC                                      | <br>AC, pulsed AC       |
| Type                                  | W35...120AB<br>CTUB103<br><br>W...AB<br>AN420<br>24 V<br>S1(k) S2(l) | W20...120<br>W1-S35...W5-S210<br><br>W...<br>W...S... | CTB31...41<br><br>CTB |
| CT: Terminal k                        | NGRM500: <b>50 mA</b>  | NGRM500: <b>50 mA</b>   | NGRM500: <b>5 A</b>  |
| CT: Terminal l                        | NGRM500: <b>C</b>  | NGRM500: <b>C</b>   | NGRM500: <b>C</b>  |

Tab. 5.1: Selecting the right measuring current transformer

### Measuring current transformer connection (W...AB)




Fig. 5.4: Measuring current transformer connection W...AB



When using a W...AB current transformer the **arrow on the top of the CT must point to the right** as shown in the wiring diagram (setting  $I_{\Delta n} > 500 \text{ mA}$ ).

### 5.6 Connection to relay outputs (Ground-fault, NGR-fault and Trip relays)




Fig. 5.5: Connection of relays, shown de-energized


## 5.7 Connection to the X1 interface

|  |    |   |
|--|----|---|
|  | I1 | Pulser IN   |
|  | I2 | Reset IN  |
|  | I3 | Test IN   |
|  | A  | Modbus RTU (A)  |
|  | B  | Modbus RTU (B)  |
|  | ↓  | Ground  |
|  | M+ | Analogue output   |
|  | Q2 | Open Collector: Pulser OUT                                |
|  | Q1 | Open Collector: System state (system health)              |
|  | +  | Output for supply of external relays (+24 V, max. 100 mA) |

Tab. 5.2: Pin assignment X1 interface

### 5.7.1 X1: Input I1...3


The input is only detected as "activated" after it has been activated for at least 150 ms. This way, short interference pulses are ignored.




Input I1...3: Potential-free contact to ground or 0 V and 24 V in conjunction with a PLC

### 5.7.2 X1: Output Q1...2


Internal 24 V



Connection to PLC



External supply e.g. 12...24 V



Connection to Q1, Q2: external relay or PLC.

i

*Observe maximum current values!*

*The maximum **output current** on X1(+24 V) is **100 mA**.*

*In case of higher currents, the relays require an external 24-V supply.*

*The maximum current on **Q1 and Q2** is **300 mA** each.*

### 5.7.3 X1: Analogue output

| Analogue output    | Mode            | Permissible load         |
|--------------------|-----------------|--------------------------|
| Current output<br> | 0...20 mA       | $\leq 600 \Omega$        |
|                    | 4...20 mA       | $\leq 600 \Omega$        |
|                    | 0...400 $\mu$ A | $\leq 4 \text{ k}\Omega$ |
| Voltage output<br> | 0...10 V        | $\geq 1 \text{ k}\Omega$ |
|                    | 2... 0 V        | $\geq 1 \text{ k}\Omega$ |

Either NGR **current**  $I_{\text{NGR}}$  or NGR **resistance**  $R_{\text{NGR}}$  can be assigned to the analogue output. A DC voltage or current signal proportional to the measured value is applied to the output.

The following overview shows how the output signals (A or V) are proportional to the measured values ( $\Omega$  or A):





Fig. 5.6: Assignment of measured value to output signal



In "4...20 mA" and "2...10 V" mode an output signal of 0 mA or 0 V indicates a **wiring error of the analogue interface**.

## 6. User interface

### 6.1 Operating elements



Legend to operating elements

| No.                     | Description | Explanation   |
|-------------------------|-------------|---|
| <b>Display elements</b> |             |   |
| 1                       | ON          | Operation LED, green;<br>on when power supply is available  |
| 2                       |             | The LC display shows device and measurement information.  |
| 3                       | SERVICE     | The LED is on when there is either a device fault or a connection fault, and when the device is in maintenance mode.  |
| 4                       | TRIPPED     | The LED is on when the trip relay has been tripped due to an NGR fault, a ground fault or a system error.   |
| 5                       | NGR FAULT   | The LED flashes in case of a prewarning: NGR fault detected, NGR relay has tripped, trip relay has not tripped yet ( $t_{\text{NGR trip}}$ elapses).<br>The LED is on when an NGR fault has been detected. Trip relay and NGR relay have tripped. |

| No.                   | Description  | Explanation   |
|-----------------------|--------------|---|
| 6                     | GROUND FAULT | The LED flashes in case of a prewarning: ground fault detected, ground-fault relay has tripped, trip relay has not tripped yet ( $t_{GF\ trip}$ elapses).<br>The LED is on: ground fault detected, trip relay has tripped (if so configured). |
| <b>Device buttons</b> |              |   |
| 7                     | ^            | Navigates up in a list or increases a value.  |
| 8                     | MENU         | Opens the device menu.  |
|                       | ESC          | Cancels the current process or navigates one step back in the device menu.  |
| 9                     | RESET        | Acknowledge and resets alarms.  |
|                       | <            | Navigates backwards (e.g. to the previous setting step) or selects parameter.   |
| 10                    | TEST         | Starts the device self test.  |
|                       | >            | Navigates forwards (e.g. to the next setting step) or selects parameter.  |
| 11                    | INFO         | Shows information.  |
|                       | v            | Navigates down in a list or reduces a value.  |
| 12                    | DATA         | Indicates data and values.  |
|                       | OK           | Confirms an action or a selection.  |
| <b>Interfaces</b>     |              |   |
| 13                    | X1           | Interface X1 (details see <a href="#">page 28</a> )   |
| 14                    | ETH          | Ethernet interface  |
| 15                    | R on/off     | Terminating resistor for A/B (Modbus RTU)   |
| <b>Buzzer</b>         |              | Active in case of alarm and/or test   |


Tab. 6.1: Legend to operating elements

## 6.2 Standard display




The pulse symbol in the lower part of the display indicates that the resistance of the  $R_{\text{NGR}}$  is actively measured.


### 6.3 Fault indication (active)




Return from any (sub)menu to the **standard display** by pressing and holding **ESC** for more than 2 s.

An active fault is indicated on the display with a  while the upper part of the display turns orange and indicates the fault message. Depending on the fault type, the GROUND FAULT, NGR FAULT, TRIPPED or SERVICE LEDs will be on. If several fault messages appear, navigate through the faults using the  $\nabla$  and  $\wedge$  buttons.

## 6.4 Fault indication (inactive)



An inactive fault is indicated on the display with a . If more than one fault has occurred, the number of faults is also indicated in the lower part of the display. This message means that there has been a fault in the past but the device is no longer in fault condition. If several fault messages appear, navigate through the faults using the  $\vee$  and  $\wedge$  buttons. In addition to the type of fault and the associated alarm value, fault time-of-occurrence and duration are indicated.

## 6.5 Acknowledging a fault message

In order to return to the standard display, the fault message must be acknowledged by means of the RESET button. Fault trips and messages can only be reset when the cause of fault has been eliminated.

### Acknowledging:

Press the RESET button, select "Acknowledge" and then OK to mute the buzzer (if enabled) and delete the messages from the standard display. After this, the NGR monitor returns to the standard display. No restart attempt takes place. The fault messages remain stored in the history memory.

### Reset:

Press the RESET button, select "Reset" and then OK. The buzzer is muted and the fault messages are deleted from the standard display. If the installation is de-energised, restart attempts will be carried out, which will only be successful after the fault has been eliminated. The device returns to the standard display. The faults remain stored in the history.


## 6.6 History memory



A **reset** can also be carried out via the input **I2**. It must be active for more than 150 ms.

Up to 1023 alarm messages and device errors with date and time stamp can be stored in the history memory. If the maximum number of memory entries is reached, the oldest entry will be overwritten by a new event record.

Display the history memory at MENU > 3. History



Legend, display history memory

| No. | Explanation   |
|-----|---|
| 1   | View next message   |
| 2   | Exit view   |
| 3   | Fault description<br>Alarm value  |
| 4   | ↳ Fault appeared (fault start time)<br>→ Fault disappeared (fault end time) |
| 5   | View previous message   |
| 6   | Number of the selected fault/Fault message count                            |


# 7. Menu

## 7.1 Overview

### 1. Data meas. values

$R_{NGR}$ ,  $R_{NGR}$  rel., Method,  $R_{sense}$ ,  $I_{rms}$ ,  $I_{rms}$  rel.,  $U_{rms}$ ,  $U_{rms}$  rel.,  $I_{fund}$ ,  $I_{fund}$  rel.,  $U_{fund}$ ,  $U_{fund}$  rel.,  $I_{harm}$ ,  $I_{harm}$  rel.,  $U_{harm}$ ,  $U_{harm}$  rel.

### 2. Harmonics



### 3. History

History, Delete

### 4. Pulser

Pulser,  $t_{impuls}$

### 5. Display

$R_{NGR}$ ,  $I_{NGR}$

### 6. HRG settings

|                   |   |
|-------------------|---|
| HRG system        | $U_{sys}$ (L-L), $f$ , $I_{NGR}$ nom, $R_{NGR}$ nom   |
| CT                | CT primary, CT secondary, CT connection   |
| NGR               | Method, PT primary, PT secondary  |
| Response values   | $U_{NGR}$ Trip, $I_{NGR}$ Trip, $>R_{NGR}$ , $<R_{NGR}$ , $t_{NGR}$ trip, GF trip, $t_{GF}$ trip, Alarm stored, $t_{restart}$ , Max. no. of restarts, Trip signal, Upper limit harmonics, Lower limit harmonics   |
| System settings   | Earth fault relay ..... Mode, Relay test<br>NGR relay ..... Mode, Relay test<br>Trip relay ..... Mode, Relay test<br>Analogue ..... Mode, Function<br>Digital in/out ..... System OUT, Pulser OUT, Pulser IN, Reset IN, Test IN<br>Buzzer ..... Buzzer alarm, Buzzer test |
| Field calibration |   |

### 7. Device settings

Language, Clock, Interface, Display, Password, Factory setting, Software, Service

### 8. Commissioning

Setting Language, Clock,  $U_{sys}$  L-L,  $f$ ,  $I_{NGR}$  nom,  $R_{NGR}$  nom, CT<sub>primary</sub>, CT<sub>secondary</sub>, CT<sub>connection</sub>, Field calibration

### 9. Info

Device information, Software information, Clock and date information, Ethernet information

### 10. Alarm

Acknowledge, Reset, Test

## 7.2 Navigating through the menu

Select a submenu using the  $\vee$  and  $\wedge$  buttons and press OK or  $>$ .


Return from any submenu to the main menu by pressing ESC or  $<$ .



Return from any (sub)menu to the **standard display** by pressing and holding ESC for more than 2 s.

## 7.3 Changing settings

Enter settings with text/numbers directly. There is a corresponding representation in the menu items:



|                              |                                   |
|------------------------------|-----------------------------------|
| $\vee$ and $\wedge$ buttons: | Scroll to the letter/number.      |
| $<$ and $>$ buttons:         | Shift left and right in the word. |
| ESC:                         | Reject entry                      |
| OK:                          | Save entry                        |

## 7.4 Data measured values (menu 1)

List of measured values. Navigate through the list using the  $\nabla$  and  $\wedge$  buttons.

| Parameter       | Explanation  |
|-----------------|--|
| $R_{NGR}$       | NGR resistance value   |
| $R_{NGR\ rel}$  | NGR relative <sup>1)</sup> resistance value  |
| Method          | Measurement method (see menu 6.3)  |
| $R_{Sense}$     | Resistance value CD-series coupling device   |
| $I_{RMS}$       | Current RMS value  |
| $I_{RMS\ rel}$  | Current relative <sup>1)</sup> RMS value   |
| $U_{RMS}$       | Neutral voltage RMS value  |
| $U_{RMS\ rel}$  | Neutral voltage relative <sup>1)</sup> RMS value   |
| $I_{fund}$      | Current RMS value (fundamental frequency)  |
| $I_{fund\ rel}$ | Current relative <sup>1)</sup> RMS value (fundamental frequency)                                       |
| $U_{fund}$      | Neutral voltage RMS value (fundamental frequency)  |
| $U_{fund\ rel}$ | Neutral voltage relative <sup>1)</sup> RMS value (fundamental frequency)                               |
| $I_{harm}$      | Current RMS value (for selected harmonic frequency range) <sup>2)</sup>                                |
| $I_{harm\ rel}$ | Current relative <sup>1)</sup> RMS value (for selected harmonic frequency range) <sup>2)</sup>         |
| $U_{harm}$      | Neutral voltage RMS value (for selected harmonic frequency range) <sup>2)</sup>                        |
| $U_{harm\ rel}$ | Neutral voltage relative <sup>1)</sup> RMS value (for selected harmonic frequency range) <sup>2)</sup> |

Tab. 7.1: Data measured values (menu 1)

### Note

- 1) Relative measured values always indicate the ratio of the measured value to the nominal value in percent.
- 2) The selected harmonics (filter bandwidth) are configured in the menu 6.5.11 and 6.5.12.

## 7.5 Harmonics (menu 2)

The measured harmonics are represented in a bar graph as a percentage of the measured value in relation to the nominal value. Change between the harmonic **voltage** and **current** displays using the  $\nabla$  and  $\wedge$  buttons.

Scroll through the **harmonics up to the 64<sup>th</sup> order** using the  $<$  and  $>$  buttons.



*All harmonics are always displayed, regardless of the settings in the menus 6.5.11 and 6.5.12.*

Use ESC to return to the main menu.

## 7.6 History (menu 3)

Alarm messages (since switching on the device or deleting the last history) are saved.

**History:** Navigate through the list using the  $\vee$  and  $\wedge$  buttons.

**Delete:** After confirming, the history is irreversibly deleted.

## 7.7 Pulser (menu 4)

A ground fault can be located by means of a measuring clamp and the pulser function. The pulser relay is designed as Open Collector.

### Pulser (menu 4.1)

- **Active** - The pulser is continuously active regardless of ground faults that have occurred.
- **External** - The external input "Pulser In" can activate the pulser at any time.
- **Auto** - The pulser activates automatically in the event of a ground fault.
- **Inactive** - The pulser output is disabled.

### $t_{\text{pulse}}$ (menu 4.2)

The pulse period can be set between 1...10 s.



*The set pulse period is only effective if the pulser (menu 4.1) is not "inactive".*

The following diagram shows an overview of the pulser control:

### Pulser control




Fig. 7.1: Pulser control

## 7.8 Display (menu 5)

Choose whether the measured values for  $R_{NGR}$  and  $I_{NGR}$  should be displayed as absolute (in  $\Omega$  or A) or relative (in % to the reference value). The relative value is the ratio of the measured value to the nominal value.

## 7.9 HRG settings (menu 6)

### 7.9.1 HRG system (menu 6.1)

| Menu  | Parameter       | Setting range                                     | Explanatory notes  |
|-------|-----------------|---|--|
| 6.1.1 | $U_{sys}$ (L-L) | 400 V...25 kV                                     | System phase-to-phase voltage  |
| 6.1.2 | CD-NGRM         | CD1000,<br>CD5000,<br>CD14400<br>CD25000<br>Other | For CD1000 and CD1000-2, select "CD1000" in the menu.<br>The selection depends on the system voltage $U_{sys}$ . |
| 6.1.3 | Frequency       | 50 or 60 Hz                                       | Nominal frequency  |
| 6.1.4 | $I_{NGR nom}$   | 0.5...100 A                                       | Nominal value of the NGR current   |
| 6.1.5 | $R_{NGR nom}$   | 15...5000 $\Omega$                                | Nominal value of the used NGR resistance   |

Tab. 7.2: HRG system (menu 6.1)

### 7.9.2 CT (menu 6.2)

| Menu  | Parameter     | Setting range | Explanatory notes                     |
|-------|---------------|---------------|---------------------------------------|
| 6.2.1 | CT primary    | 1...10,000    | Ratio of the CT on the primary side   |
| 6.2.2 | CT secondary  | 1...10,000    | Ratio of the CT on the secondary side |
| 6.2.3 | CT connection | 5 A, 50 mA    | Used CT connection                    |

Tab. 7.3: CT (menu 6.2)

### 7.9.3 NGR (menu 6.3)

| Menu  | Parameter    | Setting range | Explanatory notes   |
|-------|--------------|---------------|---|
| 6.3.1 | Method       | auto, passive | <b>auto:</b> automatic changeover between active and passive resistor monitoring<br><b>passive:</b> only passive resistor monitoring (see <a href="#">page 14</a> ) |
| 6.3.2 | PT primary   | 1...10,000    | Ratio of the potential transformer on the primary side  |
| 6.3.3 | PT secondary | 1...10,000    | Ratio of the potential transformer on the secondary side  |

Tab. 7.4: NGR (menu 6.3)

### 7.9.4 Response values (menu 6.4)

#### Behaviour of the trip relay in the event of a ground fault

Set whether a ground fault (response value violation  $U_{NGR}$  and/or  $I_{NGR}$ ) should switch the Trip relay or not. Set the filter type for NGR current and voltage ("total RMS", "fundamental", or "harmonics") that leads to a violation of the response value at "Trip signal" (menu 6.5.10).

#### a) Ground-fault trip (GR trip) (menu 6.4.6) "on"

When a *ground fault* is detected

- the **ground-fault relay** (connections 11, 12, 14) switches **immediately** (40 ms).
- the **trip relay** (connections 31, 32, 34) switches **after  $t_{GF\ trip}$  has elapsed**.

#### b) Ground-fault trip (GR trip) (menu 6.4.6) "off"

When a *ground fault* is detected

- the **ground-fault relay** (connections 11, 12, 14) switches **immediately** (40 ms).
- the **trip relay** (connections 31, 32, 34) **does not** switch,  $t_{GF\ trip}$  is ignored.

## Resistor faults

*Resistor faults* (response value violation  $R_{NGR}$ ) are independent of the "GR trip" settings: The **NGR fault relay** (connections 21, 22, 24) switches within the response time of approximately 7.5 s. The **Trip relay** (connections 31, 32, 34) switches with a **delay** according to the  $t_{NGR \text{ trip}}$  setting.

### Restart of the installation (Auto-reset: restart attempts)

Set whether the installation should be restarted manually or automatically after a ground fault or resistor fault.

#### a) Restart installation manually (alarm stored (menu 6.4.8) "on")

In the event of a fault, the Trip relay changes state and the installation shuts down (if so configured). The fault must be eliminated and the relay trip/installation is restarted via a manual reset (menu 9), via RESET key or via input I2. If the restart is not successful, it must be retried (after further fault elimination).

#### b) Restart installation automatically (alarm stored (menu 6.4.8) "off")

In the event of a fault, the Trip relay changes state and the installation shuts down (if so configured). The fault must be eliminated. After the configured time delay  $t_{\text{restart}}$  has elapsed, the NGRM500 attempts to restart the installation automatically. The Trip relay switches from the tripped state and, if the fault condition is still present, it will trip again after the set delay. If the restart is not successful,  $t_{\text{restart}}$  elapses again and another restart attempt takes place. The number of restart attempts can be selected between 1 and 5.



*The NGRM500 remains in "Alarm stored" mode (menu 6.5.8) even after a shutdown.*

## Relay and restart response values

| Menu  | Parameter              | Setting range | Explanatory notes   |
|-------|------------------------|---------------|---|
| 6.4.1 | $U_{NGR \text{ trip}}$ | 10...90 %     | Value in % of the nominal value at which the ground-fault relay trips. The Trip relay only trips (with the configured delay) when the ground-fault trip is set to "on" (6.5.6). |
| 6.4.2 | $I_{NGR \text{ trip}}$ | 10...90 %     |   |
| 6.4.3 | $> R_{NGR}$            | 110...200 %   | High or low resistance value in % of the nominal value at which the Trip relay and the NGR relay operate.   |
| 6.4.4 | $< R_{NGR}$            | 10...90 %     |   |

| Menu   | Parameter   | Setting range | Explanatory notes   |
|--------|---|---------------|---|
| 6.4.5  | $t_{\text{NGR trip}}$<br>On the device:<br>$t(\text{NGRtrip})$    | 0...60 s      | Time delay between NGR fault detection and shutdown by the trip relay. $t_{\text{NGR trip}}$ is added to the response time.   |
| 6.4.6  | Ground-fault trip   | on            | <b>Ground fault:</b> Trip relay switches after the time delay $t_{\text{trip}}$ has elapsed.<br><b>NGR fault:</b> Trip relay switches immediately (< 7.5 s) or after the time delay $t_{\text{NGR trip}}$ (0...60 s) has elapsed. |
|        |   | off           | <b>Ground fault:</b> Trip relay does not switch.<br><b>NGR fault:</b> Trip relay switches immediately (< 7.5 s) or after the time delay $t_{\text{NGR trip}}$ (0...60 s) has elapsed.   |
| 6.4.7  | $t_{\text{GF trip}}^{1)}$<br>On the device:<br>$t(\text{GFtrip})$ | 100 ms...24 h | Time delay between ground-fault detection and operation of the Trip relay; only used when ground-fault trip is set to "on" (6.5.6).   |
| 6.4.8  | Alarm stored  | on            | Triggered Trip relay must be reset <b>manually</b> (RESET or input I2)  |
|        |   | off           | <b>Automatic</b> restart attempts after $t_{\text{restart}}$ has elapsed (max. number like setting 6.5.9)   |
| 6.4.9  | $t_{\text{restart}}$<br>On the device:<br>$t(\text{restart})$     | 100 ms...24 h | Time delay between fault elimination and automatic restart; only used when alarm stored (6.5.8) is set to "off".  |
| 6.4.10 | Restart count   | 1...5         | Number of restart attempts within 24 h; only used when alarm stored (6.5.8) is set to "off".  |

| Menu   | Parameter            | Setting range  | Explanatory notes   |
|--------|----------------------|--|---|
| 6.4.11 | Trip signal          | RMS  | Trips on the full-spectrum RMS value ( $f = \text{DC} \dots 3.8 \text{ kHz}$ ).   |
|        |                      | Fundamental  | Trips on the RMS value of the fundamental.  |
|        |                      | Harmonics  | Trips on the RMS value within the harmonic filter upper and lower limits (6.5.11 and 6.5.12).   |
| 6.4.12 | Upper limit harmonic | 0...32:<br>0 = DC<br>1 = fundamental<br>2 = 2 <sup>nd</sup> harmonic | Indicate range of harmonics that will trigger the Trip relay and Ground-fault relay if the threshold value has been exceeded; only active when "Harmonics" is selected at 6.5.10. |
| 6.4.13 | Lower limit harmonic | ...<br>32 = 32 <sup>nd</sup> harmonic                                |   |

Tab. 7.5: Response values (menu 6.4)

**Note:**

- 1) Observe the maximum trip time (see [Tab. 8.1](#)) and the restart time ( $t_{\text{restart}}$ ) for the installed CD-series coupling device when setting the time delay  $t_{\text{trip}}$ .

### 7.9.5 System settings (menu 6.5)

| Menu  | Parameter          |                      | Setting range            | Explanatory notes |
|-------|--------------------|----------------------|--------------------------|-------------------|
| 6.5.1 | Ground-fault relay | Mode (6.5.1.1)       | Fail-safe, non-fail-safe | 1)                |
|       |                    | Relay test (6.5.1.2) | on, off                  | 2)                |
| 6.5.2 | NGR relay          | Mode (6.5.2.1)       | Fail-safe, non-fail-safe | 1)                |
|       |                    | Relay test (6.5.2.2) | on, off                  | 2)                |
| 6.5.3 | Trip relay         | Mode (6.5.3.1)       | Fail-safe, non-fail-safe | 1)                |
|       |                    | Relay test (6.5.3.2) | on, off                  | 2)                |

| Menu  | Parameter              |                             | Setting range   | Explanatory notes   |
|-------|------------------------|-----------------------------|---|---|
| 6.5.4 | Analogue               | Mode (6.5.4.1)              | 0...20 mA<br>4...20 mA<br>0...400 $\mu$ A<br>0... 10 V<br>2... 10 V | 3)  |
|       |                        | Function (6.5.4.2)          | $I_{NGR}$ , $R_{NGR}$   |   |
| 6.5.5 | Digital inputs/outputs | System health OUT (6.5.5.1) | Fail-safe, non-fail-safe  | 1)  |
|       |                        | Pulser OUT (6.5.5.2)        | Fail-safe, non-fail-safe  |   |
|       |                        | Pulser IN (6.5.5.3)         | Active high<br>Active low   | <b>Active high:</b> Activation of the function when input level changes from "low" to "high"<br><b>Active low:</b> Activation of the function when input level changes from "high" to "low" |
|       |                        | RESET IN (6.5.5.4)          |   |   |
|       |                        | TEST IN (6.5.5.5)           |   |   |
| 6.5.6 | Buzzer                 | Buzzer alarm (6.5.6.1)      | on, off   | <b>on:</b> each alarm activates buzzer<br><b>off:</b> alarm does not activate buzzer  |
|       |                        | Buzzer test (6.5.6.2)       | on, off   | <b>on:</b> test activates buzzer<br><b>off:</b> test does not activate buzzer   |

Tab. 7.6: System settings (menu 6.5)

**Legend, Tab. 7.6**

- 1) Fail-safe: The relay is energised during normal operation and is de-energised in the event of a fault  
Non-fail-safe: The relay is de-energised in normal operation and is energised in the event of a fault
- 2) When set to "on", the function of the relay is checked during a test by switching it.
- 3) Analogue output (menu 6.5.4)  
Either NGR **current**  $I_{NGR}$  or NGR **resistance**  $R_{NGR}$  can be assigned to the analogue output. In doing so, the voltage or current is proportional to the measured value. See [chapter 9.1](#) for more details.

### 7.9.6 Field calibration (menu 6.6)

During field calibration, all tolerances of the connected CD-series coupling device and the NGR are taken into account. The measured value is calibrated to the set nominal value of the NGR ( $R_{\text{NGR nom}}$ ).

In order to achieve high accuracy, start the device and let it run for at least one hour in the operating environment before carrying out the field calibration.



*The Trip relay is switched during field calibration!*

### 7.10 Device settings (menu 7)

Further information on configurable parameters can be found in the following table.

| Menu | Parameter |                     | Note  |
|------|-----------|---------------------|---|
| 7.1  | Language  |                     | German<br>English GB<br>English US<br>Spanish<br>French |
| 7.2  | Clock     | Time (7.2.1)        | Set local time  |
|      |           | Format (7.2.2)      | 12 h (am/pm)<br>24 h                                    |
|      |           | Summer time (7.2.3) | Automatic change? <sup>1)</sup>                         |
|      |           | Date (7.2.4)        | Set date  |
|      |           | Format (7.2.5)      | dd.mm.yy<br>mm-dd-yy                                    |
|      |           | NTP (7.2.6)         | Synchronisation on/off <sup>2)</sup>                    |
|      |           | NTP server (7.2.7)  | IP address NTP server                                   |
|      |           | UTC (7.2.8)         | Time zone <sup>3)</sup>                                 |

| Menu | Parameter               |                            | Note  |                                |
|------|-------------------------|----------------------------|---|--------------------------------|
| 7.3  | Interface <sup>4)</sup> | Write access (7.3.1)       | Allow, deny   |                                |
|      |                         | Ethernet (7.3.2)           |   | DHCP (7.3.2.1)                 |
|      |                         |                            |   | IP (7.3.2.2)                   |
|      |                         |                            |   | SN (7.3.2.3)                   |
|      |                         |                            |   | Std.GW (7.3.2.4)               |
|      |                         |                            |   | DNS server (7.3.2.5)           |
|      |                         |                            |   | Domain                         |
|      |                         | BCOM (7.3.3)               |   | System name (7.3.3.1)          |
|      |                         |                            |   | Subsystem (7.3.3.2)            |
|      |                         |                            |   | Device address (7.3.3.3)       |
|      |                         |                            |   | Timeout (7.3.3.4)              |
|      |                         |                            |   | TTL for subscription (7.3.3.5) |
|      |                         | Modbus TCP (7.3.4)         |   | Port 502 (7.3.4.1)             |
|      |                         | Modbus RTU (7.3.5)         |   | Address (7.3.5.1)              |
|      | Baud rate (7.3.5.2)     |                            |   |                                |
|      | Parity (7.3.5.3)        |                            |   |                                |
|      | Stop bits (7.3.5.4)     |                            |   |                                |
| 7.4  | Display <sup>5)</sup>   | Brightness (7.4.1)         | 0...100 %   |                                |
|      |                         | Decimal separators (7.4.2) | Comma, point  |                                |
| 7.5  | Password                | Password (7.5.1)           | Factory setting 0000                                |                                |
|      |                         | Status                     | on, off   |                                |
| 7.6  | Factory settings        |                            | Changes are discarded and reset to factory settings |                                |
| 7.7  | Software                | Update via interface       | 6)  |                                |
|      |                         | UPDATE                     |   |                                |
| 7.8  | Service                 | For Bender service only    |   |                                |

Tab. 7.7: Device settings overview (menu 7)

### Explanatory notes Tab. 7.7

#### 1) **Summer time (menu 7.2.3)**

**off** No automatic change between summer time and standard time.

#### **DST** **Daylight Saving Time**

Automatic change between summer time and standard time according to North American regulation. North American summer time begins on each second Sunday in March at 02:00 local time by setting the clock forward by one hour from 02:00 to 03:00 local time. Summer time always ends the first Sunday in October at 03:00 local time by setting the clock back one hour from 03:00 to 02:00.

#### **CEST** **Central European Summer Time**

Automatic change between summer time and standard time according to Central European regulation. Central European summer time begins on each last Sunday in March at 02:00 CEST by setting the clock forward by one hour from 02:00 to 03:00. Central European summer time always ends on the last Sunday in October at 03:00 CEST by setting the clock back one hour from 03:00 to 02:00.



*When set to "DST" or "CEST", changing between summer time and normal time is only done on the date of the official time change.*

#### 2) **NTP (menu 7.2.6)**

**on** Synchronisation via NTP server is enabled. To use this function, configure the NTP server.

**off** Synchronisation is disabled.

#### 3) **UTC (menu 7.2.8)**

Set the time according to UTC (Coordinated Universal Time). For Germany, set +1 for wintertime (MEZ) and +2 for summer time (MESZ).

### 4) **Interface (menu 7.3)**

Set the parameters for connecting other communication devices to the NGRM500 in the interface menu:

#### **Write access (menu 7.3.1)**

Set whether the parameters of the device can be changed via Modbus and web server. Displaying and reading out data via Modbus and web server is always possible, regardless of this setting.

- **Allow** Allow external parameter setting.
- **Deny** Deny external parameter setting.

#### **Ethernet (menu 7.3.2)**

Set the parameters for communication with other devices via the Ethernet interface. The Ethernet interface can be used for communication with Modbus, web server and BCOM.

#### **DHCP (menu 7.3.2.1)**

**on** Enable automatic IP address assignment (IP address, subnet mask, standard gateway). Manual address settings are ignored.

- o f f Disable automatic IP address assignment. Enter settings (IP address, subnet mask and standard gateway) manually in the menu



*The used IP address is displayed in the Info menu (INFO button or menu 9).*

#### **IP (menu 7.3.2.2)**

Set the appropriate IP address for the NGRM500.

#### **SN (menu 7.3.2.3)**

Set the appropriate subnet mask.

#### **Std. GW (menu 7.3.2.4)**

If a standard gateway is used, enter the IP address here.

#### **DNS server (menu 7.3.2.5)**

If a DNS server is used, enter the server's IP address. For questions regarding the configuration of a DNS server, please contact your network administrator.

#### **Domain (menu 7.3.2.6)**

Enter the domain. For questions regarding the configuration of the domain, please contact your network administrator.

#### **BCOM (menu 7.3.3)**

Set the parameters for communication with other devices via BCOM. For further information, refer to "BCOM" on [page 48](#).

#### **System name (menu 7.3.3.1)**

Enter the system name of the network in which the devices are located. In order to guarantee that all devices are able to communicate via BCOM, all devices must have the same system name.

#### **Subsystem (menu 7.3.3.2)**

Configure the subsystem address of the network in which the devices are located. The devices can communicate with subsystems with the same or different subsystem addresses.

#### **Device address (menu 7.3.3.3)**

Assign a device address. Each device must have a different address to distinguish it from others in the system and ensure correct communication.

#### **Timeout (menu 7.3.3.4)**

Set the timeout for messages between 100 ms...10 s. This time specification defines the maximum permissible time for a device to respond.

#### **TTL for subscription (menu 7.3.3.5)**

Set a time between 1 s...1092 min. This time determines in what intervals the NGRM500 sends messages to e.g. a gateway. Severe alarms are always sent immediately.

### **Modbus TCP (menu 7.3.4)**

Settings for communication with other devices via Modbus TCP.

#### **Port 502 (menu 7.3.4.1)**

Choose whether Modbus TCP should be used:

- on Modbus TCP can be used for communication with other devices.
- off Modbus TCP cannot be used for communication with other devices.

### **Modbus RTU (menu 7.3.5)**

Settings for communication with other devices via Modbus RTU.

Address (menu 7.3.5.1): 1...247

Baud rate (menu 7.3.5.2): the selectable options are

- 9.6 kbaud,
- 19.2 kbaud,
- 38.4 kbaud,
- 57.6 kbaud

Parity: the selectable options are "even", "odd", "none"

Stop bits: the selectable options are "1", "2", "auto"

## 5) **Display (menu 7.4)**

### **Brightness (menu 7.4.1)**

Adjust the display brightness between 0...100 % in steps of 10. If no button is pressed on the display for 15 minutes, the brightness of the display decreases. After pressing a button, the display returns to the initial brightness.

## 6) **Software (menu 7.7)**

### **Update via interface (menu 7.7.1)**

- off Software updates cannot be carried out via the web interface
- on Software updates can be carried out via the web interface

### **UPDATE (menu 7.7.2)**

If a software package has been transferred to the device, the package can be installed (again) here.

## 7.11 Commissioning (menu 8)

The commissioning wizard queries all relevant parameters.

|                          |                       |
|--------------------------|-----------------------|
| Language (8.2)           | Select                |
| Date (8.3)               | Set                   |
| Time (8.4)               | Set                   |
| Usys L-L (8.5)           | System voltage        |
| Frequency (8.6)          | 50 or 60 Hz           |
| INGR nom (8.7)           |                       |
| RNGR nom (8.8)           |                       |
| CT primary (8.9)         |                       |
| CT secondary (8.10)      |                       |
| CT connection (8.11)     | 50 mA or 5 A          |
| Field calibration (8.12) | Start or do not start |

## 7.12 Info (menu 9)

The NGRM500's settings can be viewed in the Info menu. Navigate through the different views using the arrow buttons:

|          |  |
|----------|--|
| Device   | Name, serial number, article number                          |
| Software | Measurement equipment software version, HMI software version |
| Clock    | Time, date, summer time                                      |
| Ethernet | IP address, DHCP status, MAC address                         |

## 7.13 Alarm (menu 10)

|             |  |
|-------------|--|
| Acknowledge | Mute buzzer, delete message from the standard display, fault message remains stored in the history memory. If the installation is de-energised, no restart attempts will take place.   |
| Reset       | Mute buzzer, delete message from the standard display, fault message remains stored in the history memory. If the installation is de-energised, restart attempts will be carried out, which will only be successful after the fault has been eliminated. The device returns to the standard display. |
| Test        | Since the relays are not monitored in the hardware or software, the relays must be tested at regular intervals on proper functioning. The frequency of the test cycle is subject to the safety requirements of the operator but it should be carried out at least every six months.                  |



*During the test it must be ensured that the relays can actually switch! The following settings are required:*

Ground-fault relay **menu 6.6.1.2** relay test "on"  
 NGR relay **menu 6.6.2.2** relay test "on"  
 Trip relay **menu 6.6.3.2** relay test "on"

## 8. Initial commissioning

The following parameters must be entered for initial commissioning:

- **System voltage  $U_{sys}$**  (phase-to-phase)  
The corresponding coupling device must be used depending on the system voltage:  
for  $U_{sys} \leq 4.3$  kV: CD1000, CD1000-2, CD5000 (20 k $\Omega$ )  
for  $U_{sys} > 4.3$  kV: CD14400, CD25000 (100 k $\Omega$ )
- **Ratio of the used potential transformer ( $U_{NGR nom}$ )** if used
- **NGR rated current ( $I_{NGR nom}$ )**
- **Ratio of the used measuring current transformer**  
(600:1 for W... and W...AB measuring current transformers)
- **NGR rated resistance  $R_{NGR nom}$**



Parameters are set in the

**main menu > 6. HRG settings.**

Alternatively, you can follow the setup wizard (**Main menu > 8. Commissioning**).

### 8.1 Response values

The following parameters can be adjusted:

- Trip threshold for voltage ( $U_{NGR}$ )
- Trip threshold for current ( $I_{NGR}$ )
- Trip thresholds for resistance ( $R_{NGR}$ )



**Low trip threshold values** may lead to **false tripping**, while with **high trip threshold values** the device may not trip at all.

#### Voltage trip threshold ( $U_{NGR}$ )

The threshold is set as a percentage of  $U_{NGR nom}$ .

Setting range of trip threshold  $U_{NGR}$ : 10...90 % (factory setting 60 %)

#### Current trip threshold ( $I_{NGR}$ )

The trip threshold is set as a percentage of  $I_{NGR nom}$ .

Setting range of trip threshold  $I_{NGR}$ : 10...90 % (factory setting 60 %).

### Resistance trip thresholds ( $R_{NGR}$ )

Both trip thresholds for resistance are set as a percentage of  $R_{NGR\ nom}$ .

Setting range of trip threshold  $R_{NGR}$

10...90 % (factory setting 50 %)

110...200 % (factory setting 200 %).

In the case of the **passive measurement method** the resistance  $R_{NGR}$  is determined using the current and voltage measurements. Accuracy depends on the measuring current transformer.

In the case of the **active measurement method** the device generates an active test pulse and measures  $R_{NGR}$  even if the installation is de-energised.

## 8.2 Output relays operating modes

The factory setting for the relays is fail-safe. In the case of a device test, the relays change state. The settings can be changed in *menu 6.6.1...6.6.6* (see [page 45](#)).

### 8.2.1 Field calibration

After the parameters have been entered, a field calibration must be carried out. During this process, the set nominal resistance value of the NGR calibrates to the measured resistance.



*Start field calibration in the  
main menu > 6.7 Field calibration.*

If calibration is not possible (e.g. due to incorrect settings) an error message appears (6.10).

### 8.2.2 Trip times

The three relays have different trip times:

- Ground-fault relay      40 ms, not configurable
- NGR fault relay          7.5 s, not configurable
- Trip relay                  100 ms...24 h, configurable for ground faults;  
0...60 s, configurable for NGR faults

### Explanatory notes on Trip relay


- In case of a ground fault,  $t_{GF \text{ trip}}$  is only considered when "GR trip" (menu 6.5.6) is enabled. When "GR trip" is disabled, the trip relay does not switch in the event of a ground fault.
- In case of an NGR fault,  $t_{GF \text{ trip}}$  is ignored, the trip relay switches after time delay  $t_{NGR \text{ trip}}$  has elapsed.
- The setting for  $t_{GF \text{ trip}}$  must under no circumstances be longer than the maximum possible operating time of the CD-NGRM... coupling device.

The table shows an overview of the  $t(GFtrip)$  settings for the coupling device used:

| $U_{sys}$       | Coupling device | Max. $t_{trip}$<br>(Menu 6.5.7) | Ground-fault trip settings<br>(menu 6.5.6) |
|-----------------|-----------------|---------------------------------|--|
| 400...690 V     | CD1000          | 24 h                            | on or off                                  |
|                 | CD1000-2        |                                 |  |
| 691...1000 V    | CD1000          | 300 s                           | on   |
|                 | CD1000-2        | 24 h                            | on or off                                  |
|                 | CD5000          |                                 |  |
| 1001...4300 V   | CD5000          | 24 h                            | on or off                                  |
| 4301...14550 V  | CD14400         | 60 s                            | on   |
|                 | CD25000         |                                 |  |
| 14551...25000 V | CD25000         | 10 s                            | on   |


Tab. 8.1: Maximum trip times  $t(GFtrip)$  for the used CD-NGRM

**Ground-fault relay timing diagram**



*Fig. 8.1: Ground-fault relay timing diagram*

**NGR relay timing diagram**



*Fig. 8.2: NGR relay timing diagram*

### 8.3 Trip signal: RMS, fundamental, harmonics

The NGRM500 trip-signal frequency response can be selected via the "Trip signal" parameter (menu 6.5.10). Trip signal can be:

#### RMS

The RMS value of current or voltage over the entire frequency range (up to approx. 3.8 kHz).

#### Fundamental

Only the RMS value of the fundamental component (50 or 60 Hz).

#### Harmonics

The filtered RMS value of the selected range of harmonics

H0 = DC

H1 = fundamental

H2 = 2<sup>nd</sup> Harmonics

...

H32 = 32<sup>nd</sup> Harmonics



*In the "Harmonics" measured value display (menu 2) all spectral lines are always displayed. This is independent of the trip signal setting.*



*On the standard display, the measured values are indicated as*

- *resistance in  $\Omega$  or %*
- *current in A or %*

*Setting is entered in the main menu > 5: Display.*

### 8.4 Initial measurement

During device start, all measured values are recorded.



## 9. Analogue and digital I/O configuration

### 9.1 Analogue output (menu 6.6.4)

Either NGR **current**  $I_{NGR}$  or NGR **resistance**  $R_{NGR}$  can be assigned to the analogue output. A voltage or current signal proportional to the measured value is applied to the output. The following settings are possible:

#### Mode (menu 6.6.4.1)

- 0...20 mA                      Permissible load  $\leq 600 \Omega$
- 4...20 mA                      Permissible load  $\leq 600 \Omega$
- 0...400  $\mu$ A                      Permissible load  $\leq 4 \text{ k}\Omega$
- 0...10 V                          Permissible load  $\geq 1 \text{ k}\Omega$
- 2...10 V                          Permissible load  $\geq 1 \text{ k}\Omega$

For further information, see „X1: Analogue output“ on page 30.

#### Function (menu 6.6.4.2)

Set which measured values are assigned to the analogue output. Setting options:

- $I_{NGR}$
- $R_{NGR}$

### 9.2 Digital outputs (Q1, Q2)

The digital outputs can draw current (sink).

The maximum current for the Open-Collector output is 300 mA for each output.

Since the "+24 V" connection can only provide 100 mA, it might be required to use an external voltage supply (+24 V) for the relays.

### 9.2.1 Use of Q1: System condition

| Mode                 | No system error detected    | System error detected <sup>1)</sup> |
|----------------------|-----------------------------|-------------------------------------|
| <b>Fail-safe</b>     | on energised<br>Q1 low      | off de-energised<br>Q1 high         |
| <b>Non-fail-safe</b> | off de-energised<br>Q1 high | on energised<br>Q1 low              |

<sup>1)</sup> The SERVICE LED is also on

### 9.2.2 Use of Q2: Pulsar

| Mode                 | Inactive                    | Active                      |
|----------------------|-----------------------------|-----------------------------|
| <b>Fail-safe</b>     | on energised<br>Q2 low      | off de-energised<br>Q2 high |
| <b>Non-fail-safe</b> | off de-energised<br>Q2 high | on energised<br>Q2 low      |

## 9.3 Digital inputs

The inputs are detected as "activated" after the contact has been **activated (high or low) for at least 150 ms**. This way, short interference pulses are ignored.

For further information, refer to [page 28](#).

## 10. Test cycle

Since the output relays are not monitored in the hardware or software, they must be tested at regular intervals to verify proper functioning. The frequency of the test cycle is subject to the safety requirements of the operator but it should be carried out at least every six months.



*During the test it must be ensured that the relays can actually switch off!*

*The following settings are required:*

*Ground-fault relay    **menu 6.6.1.2** relay test "on"*

*NGR relay                **menu 6.6.2.2** relay test "on"*

*Trip relay                **menu 6.6.3.2** relay test "on"*

### Starting the test

Start the test by pressing the TEST button, via menu 10.3 or the input I3.



## 11. Factory settings

| Menu                             | Factory settings |
|----------------------------------|------------------|
| <b>Menu 6.1: HRG system</b>      |                  |
| 1. $U_{\text{sys (L-L)}}$        | 400 V            |
| 2. CD-NGRM                       | CD1000           |
| 3. Frequency                     | 50 Hz            |
| 4. $I_{\text{NGR nom}}$          | 5 A              |
| 5. $R_{\text{NGR nom}}$          | 470 $\Omega$     |
| <b>Menu 6.2: CT</b>              |                  |
| 1. CT primary                    | 600              |
| 2. CT secondary                  | 1                |
| 3. CT connection                 | 50 mA            |
| <b>Menu 6.3: NGR</b>             |                  |
| 1. Method                        | auto             |
| 2. PT primary                    | 1                |
| 3. PT secondary                  | 1                |
| <b>Menu 6.4: Response values</b> |                  |
| 1. $U_{\text{NGR trip}}$         | 60 %             |
| 2. $I_{\text{NGR trip}}$         | 60 %             |
| 3. $> R_{\text{NGR}}$            | 150 %            |
| 4. $< R_{\text{NGR}}$            | 50 %             |
| 5. $t_{\text{NGR trip}}$         | 0 s              |
| 6. Ground-fault trip             | yes              |
| 7. $t_{\text{GF trip}}$          | 5 s              |
| 8. Alarm stored                  | on               |
| 9. $t_{\text{restart}}$          | 5 s              |

| Menu                             | Factory settings  |
|----------------------------------|---|
| 10. Restart count                | 2   |
| 11. Trip signal                  | RMS   |
| 12. Upper limit harmonic         | 32  |
| 13. Lower limit harmonic         | 0   |
| <b>Menu 6.5: System settings</b> |   |
| 1. Ground-fault relay            | Mode: fail-safe<br>Rel. test: on  |
| 2. NGR relay                     | Mode: fail-safe<br>Rel. test: on  |
| 3. Trip relay                    | Mode: fail-safe<br>Rel. test: on  |
| 4. Analogue                      | Mode: 4-20 mA<br>Function: R NGR  |
| 5. Dig. in/out                   | System OUT: fail-safe<br>Pulser OUT: non-fail-safe<br>Pulser IN: active high<br>RESET IN: active high<br>TEST IN: active high |
| 6. Buzzer                        | Buzzer alarm: off<br>Buzzer test: on  |

## 12. Error codes

| Error code/<br>Service code | Description/Cause   | Action  |
|-----------------------------|---|---|
| 6.10                        | Error during field calibration  | Restart field calibration. If the error persists, contact Bender service.   |
| 6.11                        | Field calibration could not be started  | The installation must operate error-free before starting a field calibration. Restart field calibration. If the error persists, contact Bender service. |
| 7.61...7.63                 | Connection between measuring equipment and display unit interrupted or disturbed. | Check connection between measuring equipment and display unit. Restart device.  |
| 8.03 and 8.12               | Error in the measuring signal generation  | Restart device. If the error persists, contact Bender service.  |
| 8.43                        | Error in the internal power supply unit ( <i>positive supply voltage</i> )        | Restart device. If the error persists, contact Bender service.  |
| 8.44                        | Error in the internal power supply unit ( <i>negative supply voltage</i> )        | Restart device. If the error persists, contact Bender service.  |
| 8.46                        | Error in the internal power supply unit ( <i>supply voltage</i> )                 | Restart device. If the error persists, contact Bender service.  |
| 8.48                        | Error in the internal power supply unit ( <i>reference voltage</i> )              | Restart device. If the error persists, contact Bender service.  |
| All other error codes       |   | Contact Bender service.   |



# 13. Technical data

## 13.1 Tabular data

### Insulation coordination according to IEC 60664-1/IEC 60664-3/DIN EN 50178

#### Definitions

|  |                        |
|--|------------------------|
| Supply circuit (IC1) .....                   | (A1, A2)               |
| Measuring circuit/Control circuit (IC2)..... | (RS, E, CT), (X1, ETH) |
| Output circuit 1 (IC3) .....                 | (11, 12, 14)           |
| Output circuit 2 (IC4) .....                 | (21, 22, 24)           |
| Output circuit 3 (IC5) .....                 | (31, 32, 34)           |
| Rated voltage.....                           | 250 V                  |
| Overvoltage category.....                    | III                    |

#### Rated impulse voltage

|                        |      |
|------------------------|------|
| IC1/(IC2 . . . 5)..... | 4 kV |
| IC2/(IC3 . . . 5)..... | 4 kV |
| IC3/(IC4 . . . 5)..... | 4 kV |
| IC4/(IC5).....         | 4 kV |

#### Rated insulation voltage

|                                 |       |
|---------------------------------|-------|
| IC1/(IC2 . . . 5).....          | 250 V |
| IC2/(IC3 . . . 5).....          | 250 V |
| IC3/(IC4 . . . 5).....          | 250 V |
| IC4/(IC5).....                  | 250 V |
| Pollution degree exterior ..... | 3     |

#### Safe isolation (reinforced insulation) between

|                        |                                 |
|------------------------|---------------------------------|
| IC1/(IC2 . . . 5)..... | overvoltage category III, 300 V |
| IC2/(IC3 . . . 5)..... | overvoltage category III, 300 V |
| IC3/(IC4 . . . 5)..... | overvoltage category III, 300 V |
| IC4/(IC5).....         | overvoltage category III, 300 V |

#### Voltage tests (routine test) acc. to IEC 61010-1

|                        |           |
|------------------------|-----------|
| IC1/(IC2 . . . 5)..... | AC 2.2 kV |
| IC2/(IC3 . . . 5)..... | AC 2.2 kV |
| IC3/(IC4 . . . 5)..... | AC 2.2 kV |
| IC4/(IC5).....         | AC 2.2 kV |

### Supply voltage

|   |                                  |
|---|----------------------------------|
| Nominal supply voltage $U_S$ .....                  | AC/DC, 48...240 V                |
| for UL applications.....                            | AC/DC, 48...240 V                |
| for AS/NZS 2081 applications.....                   | AC/DC, 48...230 V                |
| Tolerance $U_S$ .....                               | $\pm 15\%$                       |
| Tolerance $U_S$ (for UL applications) .....         | -50...+15%                       |
| Tolerance $U_S$ (for AS/NZS 2081 applications)..... | -25...+20%                       |
| Frequency range $U_S$ .....                         | DC, 40...70 Hz                   |
| Power consumption (max.).....                       | $\leq 7\text{ W} / 16\text{ VA}$ |

### Monitoring $R_{NGR}$

|   |                                 |
|---|---------------------------------|
| Measuring input $R_S$ .....   | $< 33\text{ V RMS}$             |
| Measuring range NGR (with $R_S = 20\text{ k}\Omega$ ) active.....       | 0...10 k $\Omega$               |
| Measurement uncertainty for $T = 0...+40\text{ }^\circ\text{C}$ .....   | $\pm 20\%$                      |
| Measurement uncertainty for $T = -40...+70\text{ }^\circ\text{C}$ ..... | $\pm 40\%$                      |
| Measuring range NGR (with $R_S = 100\text{ k}\Omega$ ) active.....      | 0...10 k $\Omega$               |
| Measurement uncertainty for $T = 0...+40\text{ }^\circ\text{C}$ .....   | $\pm 30\%$                      |
| Measurement uncertainty for $T = -40...+70\text{ }^\circ\text{C}$ ..... | $\pm 80\%$                      |
| Setting range $R_{NGR\text{ nom}}$ .....                                | 15...5 k $\Omega$               |
| Response value $R_{NGR\text{ nom}}$ .....                               | 10...90% $R_{NGR\text{ nom}}$   |
| .....   | 110...200% $R_{NGR\text{ nom}}$ |
| Response delay NGR relay .....  | 7 s ( $\pm 2.5\text{ s}$ )      |
| Response delay Trip relay.....  | 0...60 s                        |

### Monitoring $I_{NGR}$

|                                       |                                    |
|---------------------------------------|------------------------------------|
| Measuring circuit 5 A                 |                                    |
| Nominal measuring current $I_n$ ..... | DC / 50/60 Hz / 50...3200 Hz 5 A   |
| Maximum continuous current .....      | $2 \times I_n$                     |
| Overload capacity .....               | $10 \times I_n$ for 0.03 s         |
| Measurement accuracy .....            | $\pm 2\%$ of $I_n$                 |
| Load.....                             | 10 m $\Omega$                      |
| Measuring circuit 50 mA               |                                    |
| Nominal measuring current $I_n$ ..... | DC / 50/60 Hz / 50...3200 Hz 50 mA |
| Maximum continuous current .....      | $2 \times I_n$                     |
| Overload capacity .....               | $10 \times I_n$ for 2 s            |
| Measurement accuracy .....            | $\pm 2\%$ of $I_n$                 |
| Load.....                             | 68 $\Omega$                        |

Measuring circuits 5 A and 50 mA

|   |                          |
|---|--------------------------|
| Response value $I_{NGR}$ .....                | 10... 90 % $I_{NGR nom}$ |
| Response delay Ground-fault relay.....        | ≤ 40 ms (±10 ms)         |
| Response delay Trip relay (configurable)..... | 100 ms... 24 h, ∞        |

Tolerance  $t_{trip}$  when set to

|                  |                            |
|------------------|----------------------------|
| RMS.....         | -20... 0 ms                |
| Fundamental..... | 0... +150 ms (filter time) |
| Harmonics.....   | 0... +150 ms (filter time) |

|  |                   |
|--|-------------------|
| Measuring current transformer ratio primary.....   | 1... 10,000       |
| Measuring current transformer ratio secondary..... | 1... 10,000       |
| Measuring range.....                               | 2 x $I_{NGR nom}$ |

**Coupling**

|                                      |                                  |
|--------------------------------------|----------------------------------|
| $R_S$ for $U_{sys} \leq 4.3$ kV..... | CD1000, CD1000-2, CD5000 (20 kΩ) |
| $R_S$ for $U_{sys} > 4.3$ kV.....    | CD14400, CD25000 (100 kΩ)        |

**Monitoring  $U_{NGR}$**

|   |   |
|---|---|
| $U_{NGR}$ with $R_S = 20$ kΩ.....                   | DC / 50/60 Hz / 50... 3200 Hz; (400/√3) ... ≤ (4300/√3) V         |
| $U_{NGR}$ with $R_S = 100$ kΩ.....                  | DC / 50/60 Hz / 50... 3200 Hz; > (4.3 /√3) ... (25/√3) kV         |
| Measuring range.....                                | 1.2 x $U_{NGR nom}$   |
| Overload capacity.....                              | 2 x $U_{NGR}$ for 10 s  |
| Measurement accuracy.....                           | 2 % of $U_{NGR nom}$ with $U_{NGR nom} = (U_{sys(L-L)}/\sqrt{3})$ |
| Voltage response value.....                         | 0... 90 % $U_{NGR nom}$   |
| Response delay Ground-fault relay.....              | ≤ 40 ms (±10 ms)  |
| Response delay Trip relay (configurable).....       | 100 ms... 24 h, ∞   |
| Tolerance $t_{trip}$ when set to                    |   |
| RMS.....  | -20... 0 ms   |
| Fundamental.....                                    | 0... +150 ms (filter time)  |
| Harmonics.....                                      | 0... +150 ms (filter time)  |
| PT ratio primary.....                               | 1... 10,000   |
| PT ratio secondary.....                             | 1... 10,000   |
| DC immunity in case of active $R_{NGR}$ measurement |   |
| with $R_S = 20$ kΩ.....                             | DC ±12 V  |
| with $R_S = 100$ kΩ.....                            | DC ±60 V  |

**Digital inputs**

|                               |              |
|-------------------------------|--------------|
| Galvanic separation.....      | no           |
| Length connecting cables..... | max. 10 m    |
| $U_{in}$ .....                | DC 0 V, 24 V |
| Overload capacity.....        | -5... 32 V   |

## Digital outputs

|                                       |             |
|---------------------------------------|-------------|
| Galvanic separation .....             | no          |
| Length connecting cables .....        | max. 10 m   |
| Currents (sink) for each output ..... | max. 300 mA |
| Voltage .....                         | 24 V        |
| Overload capacity .....               | -5 ... 32 V |

## Analog output (M+)

|  |  |
|--|--|
| Operating mode .....                                     | Linear   |
| Functions .....  | $I_{NGR}, R_{NGR}$   |
| Current .....  | 0 ... 20 mA ( $\leq 600 \Omega$ ), 4 ... 20 mA ( $\leq 600 \Omega$ ), 0 ... 400 $\mu$ A ( $\leq 4 \text{ k}\Omega$ ) |
| Voltage .....  | 0 ... 10 V ( $\geq 1 \text{ k}\Omega$ ), 2 ... 10 V ( $\geq 1 \text{ k}\Omega$ )                                     |
| Tolerance related to the current/voltage end value ..... | $\pm 20 \%$  |

## Ground-fault, NGR, Trip relay outputs

|  |                                      |
|--|--------------------------------------|
| Switching elements .....                                 | changeover contacts (Form C)         |
| Operating mode .....                                     | configurable fail-safe/non-fail-safe |
| Electrical endurance, number of cycles .....             | 10,000                               |
| Switching capacity .....                                 | 2000 VA / 150 W                      |
| Contact data acc. to IEC 60947-5-1                       |                                      |
| Rated operational voltage AC .....                       | 250 V/250 V                          |
| Utilisation category .....                               | AC-13/AC-14                          |
| Rated operational current AC .....                       | 5 A/3 A                              |
| Rated operational current AC (for UL applications) ..... | 3 A/3 A                              |
| Rated operational voltage DC .....                       | 220/110/24 V                         |
| Utilisation category .....                               | DC12                                 |
| Rated operational current DC .....                       | 0.1/0.2/1 A                          |
| Minimum current .....                                    | 1 mA at AC/DC > 10 V                 |

## Environment/EMC

|   |  |
|---|--|
| EMC immunity (IEC 61000-6-2 / IEC 60255-26 Ed. 3.0) ..... | DIN EN 61000-6-2   |
| EMC emission (IEC 61000-6-4 / IEC 60255-26 Ed. 3.0) ..... | DIN EN 61000-6-4   |
| Operating temperature .....                               | -40 ... +60 °C   |
| .....   | -40 ... +60 °C (for UL applications)                             |
| Humidity .....  | $\leq 98 \%$   |
| Classification of climatic conditions acc. to IEC 60721   |  |
| Stationary use (IEC 60721-3-3) .....                      | 3K5 (except condensation and formation of ice)                   |
| Transport (IEC 60721-3-2) .....                           | 2K11 (-40 ... +85 °C) (except condensation and formation of ice) |
| Long-term storage (IEC 60721-3-1) .....                   | 1K22 (-40 ... +70 °C) (except condensation and formation of ice) |

Classification of mechanical conditions acc. to IEC 60721 / IEC 60255-21 / DIN EN 60068-2-6

|                        |      |
|------------------------|------|
| Stationary use .....   | 3M7  |
| Transport .....        | 2M4  |
| Long-term storage..... | 1M12 |

**Connection**

Screw-type terminals

|  |  |
|--|--|
| Tightening torque .....  | 0.5 . . . 0.6 Nm (5 . . . 7 lb-in)               |
| Stripping length .....   | 7 mm   |
| Recommended connecting cables .....                                      | see overview <a href="#">page 22</a>             |
| rigid/flexible.....  | 0.2 . . . 2.5 mm <sup>2</sup> (AWG 24 . . . 13)  |
| flexible with ferrule with/without plastic sleeve .....                  | 0.25 . . . 2.5 mm <sup>2</sup> (AWG 24 . . . 13) |
| Multiple conductor rigid.....  | 0.2 . . . 1 mm <sup>2</sup> (AWG 24 . . . 18)    |
| Multiple conductor flexible .....  | 0.2 . . . 1.5 mm <sup>2</sup> (AWG 24 . . . 16)  |
| Multiple conductor, flexible with ferrule without plastic sleeve.....    | 0.25 . . . 1 mm <sup>2</sup> (AWG 24 . . . 18)   |
| Multiple conductor, flexible with TWIN ferrule with plastic sleeve ..... | 0.5 . . . 1.5 mm <sup>2</sup> (AWG 21 . . . 16)  |

Push-wire terminal X1

|  |   |
|--|---|
| Stripping length .....                             | 10 mm   |
| rigid/flexible.....                                | 0.2 . . . 1.5 mm <sup>2</sup> (AWG 24 . . . 16)   |
| flexible with ferrule without plastic sleeve ..... | 0.25 . . . 1.5 mm <sup>2</sup> (AWG 24 . . . 16)  |
| flexible with ferrule with plastic sleeve.....     | 0.25 . . . 0.75 mm <sup>2</sup> (AWG 24 . . . 18) |

**Other**

|  |                        |
|--|------------------------|
| Operating mode .....   | continuous operation   |
| Mounting .....   | display-oriented       |
| Altitude.....  | max. 2000 m AMSL       |
| Degree of protection, internal components (DIN EN 60529) ..... | IP30                   |
| Flammability class .....                                       | UL 94V-0               |
| Protective coating measurement equipment.....                  | SL1307, UL file E80315 |
| Weight.....  | < 500 g                |

**Standards, approvals, certifications**

The specified standards take into account the edition valid until 07.2019 unless otherwise indicated.



UL File Number: E173157

## 13.2 Ordering details

### 13.2.1 NGR monitor

| Type    | Supply voltage/Frequency range $U_S$      | Art. No.  |
|---------|---|-----------|
| NGRM500 | AC 48...240 V, 40...70 Hz / DC 48...240 V | B94013500 |

### 13.2.2 Accessories

#### CD-series coupling device

| Voltage $U_{sys}$ | Type     | Art. No.  |
|-------------------|----------|-----------|
| 400...690 V       | CD1000   | B98039010 |
| 400...1000 V      | CD1000-2 | B98039053 |
| 1000...4200 V     | CD5000   | B98039011 |
| 4300...14550 V    | CD14400  | B98039054 |
| 14551...25000 V   | CD25000  | B98039055 |

#### Measuring current transformer W...

| Frequency/Ground Fault current | Type            | Art. No.  |
|--------------------------------|-----------------|-----------|
| AC up to 10 A                  | W20             | B98080003 |
| AC up to 25 A                  | W35             | B98080010 |
|                                | W60             | B98080018 |
|                                | W0-S20          | B911787   |
|                                | W1-S35          | B911731   |
|                                | W2-S70          | B911732   |
| AC/DC up to 10 A               | W35AB           | B98080016 |
|                                | W60AB           | B98080026 |
|                                | W120AB          | B98080041 |
|                                | CTUB103-CTBC35  | B78120030 |
| AC/DC up to 25 A               | CTUB103-CTBC60  | B78120031 |
|                                | CTUB103-CTBC120 | B78120032 |

**Voltage supply for**

AC/DC measuring current transformers W...

| Type  | Supply voltage                             | Terminal            | Art. No.  |
|-------|--|---------------------|-----------|
| AN420 | AC 100...250 V, 50/60 Hz<br>DC 100...250 V | Push-wire terminal  | B74053100 |
|       |  | Screw-type terminal | B94053100 |

Measuring current transformers CTUB103...

| max. connected measuring current transformers | Type                    | Art. No.  |
|---|-------------------------|-----------|
| 2   | STEP-PS/1 AC/24 DC/0.5  | B94053110 |
| 7   | STEP-PS/1 AC/24 DC/1.75 | B94053111 |
| 17  | STEP-PS/1 AC/24 DC/4.2  | B94053112 |







# INDEX

## A

Acknowledging a fault message 35  
Alarm 52  
Analogue output 59

## B

BCOM 50

## C

CEST (Central European Summer Time) 49  
Connection  
- Measuring current transformer 26  
- Relay 27  
-  $U_{sys} > 690\text{ V}$  25  
-  $U_{sys} \leq 690\text{ V}$  23  
-  $U_{sys} \leq 690\text{ V}$  with pulser 24  
- with a zigzag transformer 25  
- X1 interface 28  
Coupling device 14  
CT 42

## D

Data measured values 39  
Delta connection 25  
Device address 50  
Device buttons 32  
Device features 13  
Device settings 47  
DHCP 49  
Digital input 60  
Digital output 59  
Display 41  
Display and operating elements 31  
Disposal 10  
DNS server 50  
Domain 50

DST (Daylight Saving Time) 49

## E

Error codes 65  
Ethernet 49

## F

Factory settings 63  
Fault indication 34, 35  
Field calibration 47, 54

## G

Glossary 12  
Ground fault 14

## H

Harmonics 39  
History 40  
History memory 36  
How to use this manual 7  
HRG settings 41

## I

Info 52  
Initial commissioning 53  
Initial measurement 57  
Intended use 11  
Interface 49  
IP 50

## M

Measurement method  
- passive 14, 54  
Menu 37  
Menu 1 39

Menu 2 39  
Menu 3 40  
Menu 4 40  
Menu 5 41  
Menu 6 41  
Menu 7 47  
Menu 8 52  
Menu 9 52  
Modbus TCP 51  
Mounting  
- DIN rail mounting 20

## **N**

NTP 49

## **O**

Ordering details 72

## **P**

Password 51  
Pulser 40

## **Q**

Q1 (Pulser) 60  
Q2 (system health) 60

## **R**

Resistor monitoring 14  
Response values 42, 53

## **S**

Service 8  
Settings 38  
SN (subnet mask) 50  
Software update 51  
Standard display 33  
Standard gateway 50

Star connection

- Usys > 690 V 25
- Usys ≤ 690 V 23

Subsystem 50

Support 8

## **T**

Technical data 67

Test cycle 61

Timing diagram

- Ground-fault relay 56
- NGR relay 56

Training courses 9

Trip signal 57

Trip threshold

- current 53
- resistance 54
- voltage 53

Trip times 54

TTL for subscription 50

## **U**

User interface 31

## **W**

Work activities on electrical installations 11

Workshops 9

Write access 49

## **X**

X1

- Analogue output 30
- Input I1...3 28
- Output Q1...2 29





## **Bender GmbH & Co. KG**

Londorfer Straße 65 • 35305 Grünberg • Germany  
Tel.: +49 6401 807-0 • [info@bender.de](mailto:info@bender.de) • [www.bender.de](http://www.bender.de)

## **USA, Mexico, Central America**

Exton PA, USA  
800.356.4266 / 610.383.9200 • [info@bender.org](mailto:info@bender.org)  
[www.bender.org](http://www.bender.org)

## **Canada • Mississauga ON, Canada**

800.243.2438 / 905.602.9990 • [info@bender-ca.com](mailto:info@bender-ca.com)  
[www.bender-ca.com](http://www.bender-ca.com)

## **South America • Santiago de Chile**

+59 2.2933.4211 • [info@bender-latinamerica.com](mailto:info@bender-latinamerica.com)  
[www.bender-latinamerica.com](http://www.bender-latinamerica.com)

© Bender GmbH & Co. KG

All rights reserved.

Reprinting only with permission of the publisher.

Subject to change!

Photos: Bender archive.



**BENDER Group**